



Operating Manual

WeightWatcher Beam





Content

1. Connection Diagram	3
2. Alarm Relays	4
3. HOLD-Function	4
4. How to Access a Parameter	4
5. How to Adjust a Parameter	5
6. Scheme of Menu	6
7. How to Calibrate the Load Measuring	7
8. Alarm Limits	8
9. How to Adjust the Display	9
10. Electric Characteristics	9
15. Installation des WeightWatcher Beam	10-13
16. Operation Instructions in Brief	14

Henning GmbH & Co. KG Industriegebiet S5 Loher Str. 4 58332 Schwelm (Germany)

Tel.:+49 2336 9298-0Fax.:+49 2336 9298-100Service-Hotline:+49 2336 9298-232

info@henning-gmbh.de www.henning-gmbh.de



weight	wate	he	1	f
		ig'		

1. Connection Diagram



Wire con	Wire configuration									
Farbe	Abk.	Belegung								
Red	RD	Supply voltage 24 V DC								
Blue	BU	Ground								
White	WH	+ Hold input								
Brown BN		- Hold input								
Green	GN	NO contact AL-1								
Yellow	YE	NC contact AL-1								
Grey	GY	COM contact AL-1								
Pink	PK	NO contact AL-2								
Black	BK	NC contact AL-2								
Violet	VT	COM contact AL-2								

2. Alarm Relays

AL-1 (change-over contact)

Changes state as soon as the load limit adjusted by **AL-** is exceeded. **AL-2** (change-over contact)

Changes state as soon as the load limit adjusted by AL - 2 is exceeded.

3. HOLD-Function

The HOLD input responds for alternating and direct voltages between 12 V to 230 V. During the elevator travel the measured loads can heavily fluctuate (friction in the rails etc.). As long as a voltage (e. g. the travel signal) between 12 to 230 V is applied at the HOLD input the alarm output through the alarm relays does not take place. If during an elevator ride a signal is presented to the HOLD input or if no signal is presented when the elevator is at standstill, the system automatically carries out a compensation of the rope weight in case of elevators with multiple suspensions as well as a compensation of the weight of a possibly existing compensation chain.

Slack Rope Alarm

There is a possibility to create negative switching thresholds by setting the first digit to minus. Slack rope situations can be detected because the measured weight is below the weight of the car.

4. How to Access a Parameter

The unit is provided with a menu offering access to the adjustable parameters.

This key is pressed to browse through the menu items. After selecting a menu item, it is used to navigate through the sub-menu. For parameters, it helps you set the parameter-value desired.

This key is pressed to select a menu item displayed, or to apply the value set for a parameter.

This key is pressed to quit the current menu item or parameter without applying the set value. By repeatedly pressing this button, you will return to displaying the current total load in the car.

Attention:

The unit automatically returns to its home-position displaying the current total load in the car, and will do that after one minute without any push of a button, regardless of which menu-item had been selected beforehand.

After ten minutes without any push of a button it changes into the energy-saving mode, i.e. the display goes off for being reactivated by the next push of a button.



weight watcher +

5. How to Adjust a Parameter

- 1.) Press button \checkmark to navigate through the parameters until the one to be adjusted is displayed.
- 2.) Press button **4** to select this parameter.
- 3.) Press button 🛃 to navigate to the value desired for the currently flashing

digit. Press button 4 to change to the next digit.

- 4.) After setting the last digit, press button
 again. After that the whole figure will be flashing.
- 5.) Press button **e** once more to apply the adjusted parameter.

6. Scheme of Menu







7. How to Calibrate the Load Measuring

Leaving the pre-adjusted menu-item Un L unchanged means that the loads are to be entered in terms of percent of the nominal load, such as for example 100% for full load and 105% for overload.

Take the following steps to calibrate the WeightWatcher Beam

- 1. Mount the rope-sensor to the upper belt
- Connect WeightWatcher Beam to a power supply ranging between 12V and 28V DC Calibrate the WeightWatcher Beam both under full load and zero-load conditions
 - a. How to Calibrate Zero Load

Purpose of this function is to compensate the weight of the empty cabin. Take the following steps:

i. By **I** navigate to menu-item **I** and select it by pressing

✓ . Then navigate by ↓ to menu-item 2Ero and select it

by pressing \checkmark . The standard value (refer to Unit) is OOO'i (0% load, i.e. empty cabin). As soon as you will have adjusted the last digit, the whole figure will be flashing.

ii. Apply it by pressing <

from **9999** to **0000**. At **0000** the current weight of the car will be measured. It goes without saying that at that moment there must not be anything in the cabin or on the car roof that does not belong there under normal operation conditions (tools!), and that there must not stay any person in the cabin or on the car roof in order not to warp the zero load parameter.

b. How to Adjust Full load

Take the following steps:

i. By ▲ navigate to menu-item [AL , and select it by pressing
▲ Then navigate by ↓ to menu-item LoAd and select it by pressing ▲. After that adjust on the display an arbitrary load to be loaded into the cabin. Unless you changed the standard of menu-item Un (L enter this load in terms of a percentage of the nominal load, i.e. 100% (100'), if you are loading the nominal load, or 75% (075') if you are going to load ¾ of the nominal

load only. As soon as you will have adjusted the last digit, the whole figure will be flashing.

ii. Apply it by pressing <

from 9999 to 0000. At 0000 the current weight of the car including load will be measured. It goes without saying that at that moment there must not be anything additional in the cabin or on the car that does not belong there under normal operation conditions (tools!), and that there must not stay any person in the cabin or on the car roof in order not to warp the full load parameter.

iii. As from now on calibration of the rope-sensor is completed and in effect.

8. Alarm Limits

Alarm limit: a designation that corresponds to the load limit in the cabin, which – if exceeded – will change the state of the alarm relay. After changing the state of the alarm-relay, the corresponding status-LED will be luminating.

AL-1 (freely programmable load)

Changes its state, if the load limit adjusted by parameter AL - I is exceeded.

AL-2 (freely programmable load)

Changes its state, if the load limit adjusted by parameter AL - 2 is exceeded.

How to Adjust the Alarm Limits:

- 1. By 🛃 navigate to menu-item ALAr and then press <
- Now in the same manner navigate to the alarm limit to be adjusted (AL 1, AL 2) and select it by pressing
- By Analysis and select it by pressing A. This will at the same time make the next digit flash.
- 4. After having adjusted the last digit and accordingly pressed <
- 5. Press **d** once more to apply the parameter.
- 6. You can quit this menu-item at any time by pressing imes.





Attention:

_

Unless you changed the standard setting of menu-item Unite the alarm limits are to be adjusted in terms of percentage, i.e. 100% for full load and 105% for overload.

9. How to Adjust the Display

Menu-item Un the offers two options. Weights and alarm limits will be displayed according to the option you choose.

Prcn (Percentage)	Weights are all displayed in terms of percentage. (preset standard) Full load equals 100% Empty cabin equals 0%
LoAd (Load)	Weights are displayed in tons.
EArA	The function <i>LR-R</i> sets the gross weight to zero; after that, only the net weight of the cabin shown.

10. Electric Characteristics

WeightWatcher Beam

Supply Voltage	12 V – 28 V DC
Power Consumption	< 1 W at 12 V DC
Fuse	1 A mT
HOLD-Input	0,8 W
Relay outputs	2
max. switching voltage	250 V AC / 220 V DC
max. starting current	2 A
max. continuous load current	30 V DC 1 A
	125 V AC 0,3 A
max. switching capacity	62 VA
(resistive load)	
max. switching capacity	62 VA
(inductive load)	
min. switching load DC	10 mV DC 0,01 mA

11. WeightWatcher Beam Installation

The sensor has to be mounted on the upper belt of the frame (see Fig. Sketch).



It is important to ensure that the sensor has to be placed centered on the upper U-profile. The surfaces of the U-profile must be smooth, so that complete contact with the sensor is guaranteed. The sensor must not wobble or do not tilt when tightening. The ratchet fittings are to be used! Unfortunately, standard screws are unsuitable for this installation.

In **version 1**, The sensor is to be positioned so, that the adjustable foot of the sensor body is brought in line with the outer edge of the cable plate, and is fitted to the U-profile. In **version 2**, The sensor body can only be placed in front of the plate. In this case, please ensure that the cable always

runs away from the centre. This applies to both versions. This applies to both versions. Pulleys are supplied.

The sensors are to be fitted at various distances (see table) to their respective profiles. Two holes (minimum diameter - 11mm) must always be drilled at a distance of 179 mm apart. This applies to all three WeightWatcher Beams.



weight watcher +

Version 1



Version 2







12. Operation Instructions in Brief

- 1.) Install the unit at an appropriate place.
- 2.) Calibrate with empty cabin

By **I** navigate to menu-item **I** local select sub-item **I** local and confirm by

. The preset standard (see Un , L) is 000', (0% cabin load, i.e. empty cabin). After setting the last digit, the whole figure will be flashing until you

confirm it by pressing <

9999 to 0000. At 0000 the current weight of the cabin will be measured. At that moment there mustn't be anybody in the cabin or on the car roof, in order not to warp the measurement. Furthermore make sure that you didn't leave any tools in the cabin or on the car roof, nor any other things that don't belong there during normal operation.

3.) Calibrate with loaded cabin (nominal load)

By **I** navigate to menu-item **I** local sub-item **L D** and confirm by

Now you can adjust on the display an arbitrary load that you will load into

the cabin. Unless you changed the preset menu-item Un it, you will have to

enter the load in terms of percentage, i.e. 100% (100'), if you load the

nominal load, or 75% ($075'_{1}$), if you load $\frac{3}{4}$ of the nominal load for example. After setting the last digit, the whole figure will be flashing until you confirm it by

pressing <

0000 the current weight of the cabin (including load!!) will be measured. At that moment there mustn't be anybody in the cabin or on the car roof, in order not to warp the measurement. Furthermore make sure that you didn't leave any tools in the cabin or on the car roof, nor any other things that don't belong there during normal operation, except the load for calibration.

- 4.) Adjust the alarm limits (see item 10)
 - By \checkmark navigate to the alarm limit and confirm by \checkmark . Scroll by \checkmark to the

value desired, then press 4 to adjust the state-changing limit. Press 4 2 times to confirm the adjustment.

5.) Connect the control lines to the lift controller and make sure that you accordingly choose the make- resp. break-contact.

Comparison of WeightWatcher, WeightWatcher light, WeightWatcher light MultiRope and WeightWatcher Beam





																am 5000		m	000 kg il 12.500 kg				U		4 x 50 mm
														ion unit		0 WW Be	456250	4 - 26 n	500 - 50 g optiona	0	•	•	0° - 70°	2,5 m	im 205 x 6
m	s connected ation unit				nmable									to the evaluat		WW Beam 220	456225	4 - 26 mm	300 - 2200 kg optional 5500 k	Strain Gaug	•	•	0° - 70°C	2,5 m	205 x 64 x 48 m
Weight Watcher Bea	WW Beam, sensor is directly to the evalu	1	12 - 28 VDC	1 W at 12 V DC	2 CO, freely progran		12 - 230 VAC/DC	•	LED, 4 digits	3 keys	•	•	•	sensor is connected		WW Beam 1200	456200	4 - 26 mm	300 - 1200 kg optional 3000 kg		•	•	0° - 70°C	2,5 m	205 x 64 x 41 mm
t MultiRope	connected tion unit				mable									to the evaluation		ultiRope 300	56700	- 26 mm	00 - 6000 kg ptional 10.000 kg				0° - 70°C	5 m	220 x 320 x 142 mm
Weight Watcher Ligh	MultiRope, sensor is directly to the evaluation	-	12 - 28 VDC	1 W at 12 V DC	2 CO, freely program		12 - 230 VAC/DC		LED, 4 digits	3 keys	•	•		sensor is connected unit		MultiRope 200 Mi	456600 45	4 - 26 mm 4	300 - 2500 kg 7	Strain Gauge	•	•	0° - 70°C	5 m	220 x 220 x 132 mm
					mmable																				
	AE8 light	8	12 - 28 VDC	0,8 W	2 CO, freely progra				LED, 5 digits	3 keys				115 x 80 x 40 mm	456100										
					ble								Ĩ												
ht Watcher Light	light		8 VDC		freely programma		30 VAC/DC		5 digits	S			pecial cable)	80 x 40 mm	00	pht	00	mm	0 kg	n Gauge			0°C		70 × 22 mm
Weigh	AE16	16	12 - 2	0,8 W	3 CO,	•	12 - 2	•	LED,	3 key:	•	•	• (s	115 x	45600	LS lig	45650	4 - 13	0 - 20	Strain	•	•	0° - 70	2,5 m	n 110 x
l					(əc											LS 2000	455850	6 - 16 mm	100 - 2000 kg	Strain Gauge	pre-cal/rope Ø	•	0° - 70°C	2,5 m	300 x 80 x 19 mr
l					overload, slack rop										05 (CanOpen)		00	0 mm	00 kg	in Gauge			0°C		58 x 16 mm
					ad, full load, o									-	Analog), 4550	LS2	4554	4 - 10	0 - 30	Strai	•	•	0° - 71	2,5 m	1 178 x
Weight Watcher	AE12	12	12 - 28 VDC	4 W	4 NO/NC (zero lo	optional	12 - 230 VAC/DC	optional	LED, 4 digits	3 keys		 (Via Laptop) 	 (USB-Cable) 	105 x 90 x 62 mm	455000, 455002 (LS 1	455500	6 - 16 mm	0 - 500 kg	Strain Gauge	• weight		0° - 70°C	2,5 m	250 x 75 x 19 mm
		Sensors		tion							f Car Weight	sistant	laptop	(H×M)		ors			٥	iple	ors	Installation	oge		(H × M
	Evaluation Unit	Max. Number Of	Voltage	Power Consump	Output Relays	Analogue Outpu	Hold Input	CanOpen	Display	Operation	Determination O	Rope Tension As	Configuration by	Dimensions (L x	ArtNo.	Rope Load Sens	ArtNo.	Rope Diameter	Measuring Rang	Measuring Princ.	Calibrated Sense	Calibration After	Temperature Rar	Length Of Cable	Dimensons (L x







= Standard
 = Not available

© Copyright 2014 by Henning GmbH & Co. KG Rev. 1.1 09/2014